

Jet pump 1 is connected to water diverter valve 1, which is connected to group A and group B water distributor. Group A water distributor is connected to the A1 and A2 jets, Group B water distributor is connected to the B1 and B2 jets.

The circulation pump 1 is connected to the Group C water distributor, which is connected to the C1 jets and UV sterilizer;

Jet pump 2 is connected to water diverter valve 2, which is connected to G swim jet and group D water distributor. Group D water distributor is connected to the D1 jets.

Jet pump 3 is connected to water diverter valve 3, which is connected to K swim jet and group E water distributor. Group E water distributor is connected to the E1 jets.

Jet pump 4 is connected to I swim jet.

The circulation pump 2 is connected to the Group F water distributor, which is connected to the F1 jets; waterfall; fountain and UV sterilizer; The fountain/waterfall is controlled by 1/2 inch ball valve;

The air blower is connected to all bubble jets and aromatherapy tanks;

Jair valve is connected to the A1; A2 and C1 jets. R air valve is connected to the B1 and B2 jets.

T air valve is connected to the E1; D1 and F1 jets. M air valve is connected to the G and K swim jets.

N air valve is connected to I swim jet.

The air blower and fountain/waterfall are optional, please pay attention to the configuration and order requirements.

The dotted circle indicates the range of the point.

4pcs jet pump+ 2pc circulation pump ZR7801 Spa Front View

